



Cattle Crates

311G - Squeeze Crate

- 12 independent, fully sheeted doors
- Large 860 mm internal width
- Silent, the manually operated yoke can be operated from the entry or exit end
- Parallel squeeze of front 8 doors – reducing from 860 mm to 280 mm
- Rubber floor
- Removable 'Brisket Bar'
- Ability to fit a head scoop
- A sliding rear gate
- Access doors to the rear of the crate
- Weighing and yoke options available



310G Mobile Cattle Crate

- Manual or automatic head yoke
- Fully sheeted sides with full access to side of animal
- Access to rear of the animal from both sides
- 2 sliding gates are incorporated into the unit
- Walk-way fitted on both sides of the race-way
- Rubber floor
- Tack boxes fitted on both sides
- Hydraulic lift / lower using tractor hydraulics
- Full road lighting fitted



339G Continental Cattle Crate

- Automatic yoke with auto reset facility
- Easily adjustable neck yoke widths, which allow easy handling of calves to bulls
- Complete access to both sides of the animal with 8 doors
- Rubber floor offering improved grip and quieter working, adding to cattle safety and improved welfare
- Ratchet type rump bar operation
- Complete with rear gate and aluminium 5 bar tread-plate floor
- ideal for Continental breeds





Cattle Crates

309G - Extended Length Continental Handling Crate

- Fully automatic yoke with an auto-reset facility
- Easily adjustable neck yoke widths, allows handling of calves to bulls
- Complete access to both sides of the animal
- Rubber floor
- Ratchet type rump bar operation
- Complete with sliding rear gate and aluminium 5 bar tread-plate floor
- ideal for Continental breeds



337G Highland Cattle Handling Crate

- Heavy-duty head-lock bar incorporating a positive spring loaded catch mechanism
- Designed to provide safety for operator & minimise stress to the animal
- Complete access to both sides of the animal
- Rubber floor
- Easy adjustable neck yoke, released by pedal operation
- Ratchet type rump bar operation
- Complete with rear gate and aluminium 5 bar tread-plate floor



339G MANUAL Strathmore Cattle Crate with manual yoke

- Manual yoke operated from front or rear of crush
- Silent, manually operated yoke which requires no width adjustment, can be operated from the entry and exit side of the crate
- Complete access to both sides of animal with 8 doors
- Rubber floor
- Ratchet type rump bar operation
- Complete with rear gate and aluminium 5 bar tread-plate floor

