+ Weigh Frame
COMBI CLAMP

Sheep Weighing

Tip 1: Get Set for Weighing
Position your Combi Clamp where you plan to work. Make sure it's stable and aligned for handling.

Tip 2: Secure Your Load Bars
Bolt the load bars to the base weigh frame using the M12 fasteners. Tight, level, and ready to go!

Tip 3: Flip the Clamp
Turn the Combi Clamp on its back: this makes it easier to fit the weigh frame properly.

Tip 4: Lower and Align
Bring the clamp back down on top of the weigh frame. Line up the 2 holes at the front and 2 rear slots with the holes in the load bars.

Tip 5: Fasten It Up
Secure the Combi Clamp to the load bars using the M10 fasteners provided.
⚠️ Don't trap any cables between the clamp and frame!

Tip 6: Add the Support Bracket
Attach the race support bracket at the ramp (entry) end using the thumbscrews. Lift the race into place—race hooks slot in easily.

Tip 7: Fit the Hoof Plate (Entry)
Slide the long hoof plate into the entry end tube sockets on the clamp. This helps sheep enter smoothly onto the platform.

Tip 8: Adding a 3-Way Draft?
Only fit the exit-end support bracket if you're using the 3-way draft system (4669G-300). It goes into the shedder-side slots of the weigh frame.

Tip 9: Secure the Draft
Lift the 3-way draft into place and slot it into the support bracket. It should sit square and stable.

Tip 10: Finish with the Exit Hoof Plate
Slide the short hoof plate into the exit-end tube sockets. You're now fully set up for weighing and drafting!

RITCHIE
01307 462271
https://ritchie-d.co.uk/